

TRT Turk Set Up for DFH Hybrid Receiver


Step 1 : Press “Menu” and go to “Satellite Installation” screen.



Step 2 : Go to “Factory Default” and press “OK”



Step 3 : Press “OK” on “Yes” to proceed



Step 4 : After the “Factory Default” Satellite Installation screen will come back


Step 5 : Press “OK” on “Auto Search”



Step 6 : Press “OK” to scan channels. Make sure the receiver has signal quality before doing so.



Step 7 : It will add the new channels on the receiver and go back to “Auto Search” screen.



Step 8 : Press “Exit” button on the remote control until you get the menus off the screen.

TRT Turk will be on Channel number 14.

